



1. Before removing old tips or fairings, place masking tape on wing or fuselage next to original tip or fairing
 - If a tip, place masking tape from the leading edge to the trailing edge
 - If a fairing, it's only necessary to place masking tape near the screw holes

2. Place a straight edge over the center of the mounting screw and draw a line at approximately 45 degrees left and right onto the masking tape on the wing or fuselage

3. With the new tips or fairings installed, use the straight edge to re-align both pencil marks on the masking tape onto the new parts. Where the marks cross will be the center of each screw hole

